

1. Title	Removal of aircraft from storage and prepare for service
2. Code	EMAMAG324A
3. Range	Remove aircraft from storage and service preparation is usually carried out in an aircraft ramp and hangar during the aircraft grounded time.
4. Level	3
5. Credit	4
6. Competency	<p style="text-align: center;"><u>Performance Requirement</u></p> <p>6.1 Remove aircraft from storage</p> <ul style="list-style-type: none"> ◆ Able to identify the aircraft is matched with the aircraft registration and servicing documentation. ◆ Able to obtain and check the resources for serviceability or status in accordance with the procedures,e.g. tools, materials, equipment, procedures. ◆ Able to remove the aircraft from storage in accordance with the procedures,e.g. doors and/or panels are opened and closed. blanks, locks, chocks and covers are removed, stowed and/or fitted. bonding leads and isolation tags are connected and disconnected. inhibitors are removed. <p>6.2 Prepare aircraft for service</p> <ul style="list-style-type: none"> ◆ Able to prepare the aircraft for service in accordance with the procedures,e.g. position aircraft, inspect for condition. ◆ Able to identify locate and report the non-conformities in accordance with the procedures. ◆ Able to check and return the resources to storage for next service, or disposed of in accordance with the procedures.

	◆ Able to complete the documentation in accordance with the procedures.
7. Assessment Criteria	The integral outcome requirement of this UoC are: (i) Able to remove the aircraft from storage. (ii) Able to prepare the aircraft for service.
8. Remarks	Ref: NZQA - 3930